


YUVA INFINITY



SAFETY PRECAUTIONS

Before using this projector, make sure you read all instructions. Nothing in this handbook should be altered or created.

- Keep the projector out of the rain and moisture to lower the risk of electric shock or fire. Vases and other items with liquid contents shouldn't be set on this apparatus.
- Avoid using this projector on flimsy surfaces like carpets or tablecloths as this could cause a fire.
- This device should not be placed next to any appliance that produces a strong magnetic field or in locations that are prone to heavy dust and debris.
- Do not obstruct or clog the ventilation apertures to avoid overheating.
- Never use this projector in a small area. Make sure there is always a adequate room for airflow around this item.
- Keep this projector away from excessive heat, dampness, extreme temperature swings, and direct sunshine. Steer clear of bitter cold. This device and its accessories should be stored and operated between 0°F and 95°F.
- The surface of this projector may get hot if it is used for an extended amount of time. Quickly turn it off and disconnect the charger. Once this device has cooled down, resume using it.
- Use caution whenever handling this equipment. Keep your hands off the lens. Children should never use a device without adult supervision.

PACKAGE CONTENTS

Kindly verify the completeness of the package contents. In case of any missing items, please reach out to the distributor for prompt reissuance.



Google TV Projector

- 1** Google TV Projector
- 2** HDMI Cable
- 3** Power Cable
- 4** Bluetooth Remote
- 5** User's Manual

DEVICE OVERVIEW



1 Power ON/OFF


2 HDMI Port 

3 USB Port 

4 Audio Port 


5 Power cord interface

REMOTE CONTROL




OPERATION

- Plug the power cable to the projector, and press the power button to turn on
- Operate according to instructions:
 1. Match the Bluetooth remote control (requires extra AAA battery*2)




2. Select your region or country
3. Select and connect to your Wi-Fi network
4. Set up with your Google account and play your favorite content, or search and download your favorite Apps



DISPLAY SETTINGS


Focus

- Press the setting button/display setting button - Image Correction
- Set the Picture Focus until the image is clear.



Keystone Correction


- Press the setting button/display setting button - Image Correction
- Set the Four Trapezoid until the image is square.



DISPLAY SETTINGS


Picture

- Press the setting button/display setting button - Picture
- Adjust the Color Temperature/Picture Mode according to your preference



Audio Mode


- Press the setting button/display setting button - Audio Mode
- Adjust the Sound Mode according to your preference



DISPLAY SETTINGS


Input

- Press the sources button to choose input source according to your needs
- Or • Press the setting button - Input - Source Setting



Language


- Press the setting button/Google TV setting - Language
- Adjust the language according to your needs



DISPLAY SETTINGS


About

- Go to Settings - About
- Check the projector info here





Advance Setting

- Go to Settings - Advance Setting
- Adjust the advance setting according to your preference



SYSTEM SETTINGS

- Go to Settings on the Home page




Network & Internet



SYSTEM SETTINGS


Apps

- Check all the apps you have downloaded
- Select the unnecessary apps and uninstall



storage

- Check the memory usage of all the apps you download



INSTALLATION



- Projected onto the ceiling
- 180° Adjustable Stand
- Just place it, tilt it and watch content come to life with the Google TV smart theater that makes it simple. The cradle stand gives you floor-to-ceiling flexibility with a rotation of 180 degrees-always giving you the best view



*Note: The stand cannot be forcibly rotated beyond 180 degrees, otherwise it may cause internal cables to be twisted, which may affect some functions unusable.

Tripod Mount/Ceiling Mount

- There are 6mm (1/4") screw hole at the bottom of the stand for installing Tripod Stand or Ceiling bracket.



Design tolerance error +/- 8%

Screen size (inch)	Screen size W x H(m)	Screen size (m)
45 inch	0.99 x 0.56 m	1.09m
60 inch	1.32 x 0.74 m	1.45m
80 inch	1.77 x 0.99 m	1.92m
100 inch	2.21 x 1.24 m	2.4m
110 inch	2.43 x 1.37 m	2.64m
120 inch	2.65 x 1.49 m	2.85m

SPECIFICATION

Resolution	FHD 1920*1080 Pixels	Main Chip	Amlogic S905Y4
	Max Support 4K Videos	Content	Authorized Google TV
Brightness	500 ANSI Lumens	Storage	2G + 8G
Focus Method	Auto Focus,Digital Focus	Bluetooth	5.2
Keystone	Auto Keystone Correction, 4 Points Digital Keystone	WIFI	2.4G +5G
		Speaker	4Ω 8W speaker + Sub horn
Display Type	3.5" LCD Screen	Interfaces	HDMI/USB*2/AV/Audio
Aspect Ratio	4:3/16:9 Native	Video Format	HEVC H.265,AV11,VC-1/
Lamp Source	LED Light		VP8/VP9/,HDR 10+,HLG
Lamp Lifetime	Over 50000 hours	Audio Format	MPEG Audio Layers 1,2,3
Color	Full True Color 1.67 Million		Dolby Digital MS12
Contrast Ratio	3000:1	Power Supply	75W
Image Size	45-300Inch	Product Size	24.5*11.5*27cm(with stand)
Distance	1.09-6.2M	Weight	2.4KG

Register Warranty



Scan the QR code
to register your e-warranty now!
Registration is mandatory

DEMO VIDEO



Scan the QR code
to watch the demo video and
explore the features
of your projector

RAISE A TICKET



Scan the QR code
to submit a ticket and
get prompt assistance from
our support team.

NEED ASSISTANCE?



+91 80-7097-7097
support@wzatco.com
Our support team is available
Monday to Saturday,
10:00 AM – 5:00 PM (IST).