


WZATCO

YUVA HORIZON

USER MANUAL



Important Safety Notes!

Installation

To achieve the best effect, please use the projector in a darker room or draw the curtains. Be careful when use the projector. Any dropping or bump may lead to damaged parts, blurred images or display improperly.

Power Source

Be careful to use power cord to avoid excessive bending. Damaged power cord may cause electric shock and fire. Please be careful when using this machine. Falling or striking may damage components, blur images or display abnormally.

Cleaning

Unplug the power cord. Clean the cabinet regularly with a damp cloth. Neutral detergent can be used. Do not use strong detergents or solvents (such as alcohol and thinner). The lens should be cleaned with glasses cloth or lens paper. Be careful not to scratch the lens. Please regularly use a soft brush to clean the air inlet filter, vent and loudspeaker of the machine, other wise the vent will be blocked by dust accumulation, causing overheating of the machine, which will lead to machine failure.

High Temperature Attention

Do not disassemble the projector casually since there may be a risk of electric shock, which affects normal maintenance. Liquid or heavy objects should not be allowed to put on the machine.



Suitable for areas below 2000m altitude



Please use in an ambient temperature of 0-35 degrees Celsius.

Cautions And Warnings

1. Do not install the machine where directly blown by the air conditioner the water condensed or high temperature may cause machine failure
2. Make sure that there is sufficient ventilation and the ventilation is not blocked, so as to avoid the accumulation of hot air in the machine
3. Prevent clips or paper falling into the machine, and do not put any metal objects into machine. If accidentally happens, please turn off the power immediately and let qualified personnel fix it.
4. Due to avoid the risk of leakage, do not place any liquid on the machine.
5. When transporting the projector, please use soft packaging materialsto protect the lens from scratches please install the lens protection cover.nonviolent during transporting.
6. During or after the projection, the vicinity of the exhaust vent will become hot, non-touch with your hands.
7. Do not look into the lens while the machine is powered on, it may cause serious damage to your eyes.

NOTICE

To prevent electric shock, do not open the chassis. There are no parts in the machine that the customer can repair. Please entrust qualified professional maintenance personnel to carry out maintenance.




This sign warns the user that uninsulated voltages in the unit may cause electric shock from the surface magnetic field, and therefore it is dangerous to contact any part of the unit.



To prevent fire or electric shock,
do not expose this machine to rain or moisture

Remote Control



Note:


- 1.The remote control must be on the front and rear of the projector, if facing the image, the remote control sensitivity will decrease.
- 2.The remote control will be different as different model.

Power On

Connect the power cord to the projector and press the OK button for 3 seconds; or press the remote control at the front / rear infrared window and press the "  " power button to start the device. Shutdown: Long press the power button for 3 seconds; or point the remote control at the front / rear infrared window of the body, press "  " to select the shutdown after shutdown.


Language Setting

Go to homepage > All Settings > System > Language; select the language that you need .






Time Setting

Go to homepage> All Settings> System >Date and time; then adjust the settings based on the local time.



Installation Methods

Depending on your use environment and requirements, the projector can be hung forward with a special hanger on the ceiling or placed on a smooth desktop and projected forward onto the screen. Of course, you can also use other ways to install the projector according to the following legend.




In the Advance Setting interface, select "Projection Method" to switch.

1. When using the lifting method, the projector should not rise above the upper edge of the screen, otherwise, it will affect the effect of the image or the trapezoidal correction.
2. Be sure to install the projector on the symmetrical axis line on the left and right sides of the screen to avoid causing trapezoidal distortion on the left and right sides of the image.
3. After the installation of the projector should be well ventilated there can be no object to cover or block the vent of the projector.
4. Please do not connect the power during the installation, to avoid electric shock risk or projector circuit failure.


Image Correction

The image will automatically focus after power on or moving the projector . If the automatic focus does not reach the clearest state of the image, please press the remote control "F +" and "F -" keys to fine-tune until the image is adjusted to the clearest effect. You can enter Settings to close Autofocus function, select Lens select Autofocus settings, then turn off the automatically refocus when moved.



Keystone


The image will Auto Keystone correction after he projector raises / lowers or side projection . If the Auto Keystone correction does not reach the Ideal location of the image, please enter Settings to close Auto Keystone correction. Select Lens and select Keystone correction then turn off the Auto Keystone correction,Finally, use the 4-corner correction function to adjust the image to the ideal position.



Note: When the tilt Angle of the machine is too large, the definition of the image will decrease.


How to go to the Source Selection

Go to the home page, press the signal source button "Source" on the remote control, select the required signal source channel, such as "HDMI", "USB", and press the OK key of the remote control to enter the corresponding signal source state.




How to Connect WiFi

Go to homepage> All Settings>Network and Internet; find the network you want to connect to and press Confirm. Enter the password via the virtual keyboard and confirm the connection.





How to Use Bluetooth

Go to homepage > All Settings > Bluetooth; select "Bluetooth"; Search and select the Bluetooth that you need to pair with. For example, Bluetooth speakers, Bluetooth headphones, and Bluetooth mice.



CEC Setting

Go to homepage> All Settings>Display and sound>HDMI CEC>Enable HDMI-CEC.CEC devices such as TV sticks can be controlled remotely with remote control.



Simply Troubleshooting

The projector is easily working as TV, generally will not encounter any problems, but may be due to the near by equipment or voltage reasons, some false fault, please remove the fault before repair, if the customer still can not eliminate the fault, please contact the relevant staff.

- 1.The power supply indicator light is not on. Whether the power supply plug is well inserted properly.
- 2.Press the power button on the remote control cannot turn on. Whether the remote control battery is out of power.
Whether by the strong light to illuminate the projector receiver.
- 3.The projection with out picture. Whether the signal source selection of the projector is correct, Whether the signal source is well inserted.
- 4.After the projection for a period of time, it automatically turns off. Whether the voltage is too low, or whether the voltage fluctuates too much.
- 5.Unable to read U-disk.
Only support FAT 32, NTFS U disk format, if not the first two format, can change the format through formatting.
- 6.The picture is blurred.
Please keep the picture at least 50inch or 1.5 meters away until the picture is clear. The range of autofocus is 1.5-3 meters, beyond this range, please manually focus.

Register Warranty



Scan the QR code
to register your e-warranty now!
Registration is mandatory

DEMO VIDEO



Scan the QR code
to watch the demo video and
explore the features
of your projector

RAISE A TICKET



Scan the QR code
to submit a ticket and
get prompt assistance from
our support team.

NEED ASSISTANCE?



+91 80-7097-7097
support@wzatco.com
Our support team is available
Monday to Saturday,
10:00 AM – 5:00 PM (IST).