

宽: 8CM

高: 13CM

### 1 Safety Notice

- Please read this manual carefully before using the projector.
- Use a stable, certified power supply (100-240V, 50/60Hz).
- Always use the correct power cable supplied with the unit.
- Do not disassemble or attempt to repair the projector yourself.
- Avoid looking directly into the lens during operation.
- Ensure proper ventilation and do not block air vents.
- The projector is not waterproof; keep away from liquids.
- Disconnect power if unused for a long period.
- Avoid exposing the projector to heat, dust, or sunlight.
- Keep out of reach of children and handle carefully.
- The projector stand is fixed and not designed for removal. Do not attempt to disassemble.

### 2 Interface Overview

Power Port: Connect the supplied power cable.  
 USB Port: For media playback from a USB drive.  
 HDMI Port: For computers, consoles, or streaming devices.  
 3.5mm Audio Output: For headphones or external speakers.  
 IR Receiver: For remote control operation.

### 3 Remote control

Power: Turn projector ON/OFF  
 Input: Switch between input sources  
 Menu: Delete an installed app  
 Navigation / OK: Move and confirm  
 Volume ±: Adjust sound  
 Home: Return to main screen  
 Back: Return to previous menu  
 Ensure the remote has 2 x AAA batteries (not included)

### 4 Multimedia Connection

#### 4.1 USB Connection

Insert a USB drive with movies, music, or photos and select USB mode.

#### 4.2 HDMI Connection

Connect a PC, console, or TV stick via HDMI and select HDMI source.

**HDMI**  
 The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

#### 4.3 Audio Connection

Use 3.5mm stereo output for external audio devices.

### 5 How to Connect External Devices

- USB/Power Input**: Connect USB drives, streaming devices, or power banks.
- HDMI Port**: Connect laptops, DVD/Blu-ray players, smartphones (via adapter), or streaming boxes.
- Audio Output (AUX)**: Connect external speakers or headphones for better sound.

### 6 Wireless miracast connection

#### 6.1 Android Screen Mirroring

From the Home Page, select Screen Mirroring → Android Cast.

On your Android phone, go to Display Settings or Multi-screen Interaction, and select the projector name to begin mirroring. Ensure both the projector and your Android device are connected to the same Wi-Fi network. Different Android devices may have slightly different paths or names for this option—refer to your phone's manual for details.

Tip: The projector name may vary slightly between models. Always select the name that appears on your screen.

### 6.2 IOS Screen Mirroring

On the projector, select IOS Cast from the Screen Mirroring menu on the Home Page.

On your iPhone or iPad, open Control Centre and tap Screen Mirroring. Wait for available devices to appear, then select the projector's Cast ID to start mirroring.

Make sure your iOS device and the projector are on the same Wi-Fi network.

Note: Cast IDs differ by model. If connection fails, check that both devices are on the same network or restart the Wi-Fi connection.

### 7 Menus & Setup

From the Home Page, open Settings. You can configure:

- Wi-Fi Settings
- Bluetooth Settings
- Projection Setting: Focus, keystone correction, zoom, etc.
- Language
- Date & Time
- System Settings
- Application Settings
- Other Settings
- About

Use the navigation keys on the remote to move between options and confirm with OK.

### 8 My application

Open the Applications page from the Home Screen. Select an app to open it or press the "≡" (menu) button on the remote to delete an installed app.

Pre-installed apps may include Netflix, YouTube and other streaming or utility tools.

### 9 Specification

Light source	LED
Light source life	30000 hours
Lens	Glass lens
Focus mode	Auto/ Electric focus by remote
Keystone correction	Auto/ 4D by remote
Throw ratio	1.2:1 for 1080p; 1.32:1 for 720p
Zoom	Digital
Interface	USBx1 / HDMIx1 / 3.5mm audio out
Working noise	<36 dB
Aspect ratio	16/9 / 4:3 / Auto-fit
Speaker	5W x 1
Product size	220×70×240 mm with bracket 184×68×192 mm without bracket
Net weight	1.4 kg with bracket 1.04 kg without bracket
Power Input	100-240V AC 50/60Hz
Power consumption	80W
Remote battery	2×AAA (not included)
Android version	Android 12.0 ADSP
Light engine	Sealed dust free
Resolution	Native 1080p

### 1080p projector distance & size

Note: Due to optics error of 3%, the data above is for reference only, please use actual measurement when install the device.

### 10 Trouble Shooting

Issue	Possible Cause	Solution
No power	Loose cable or socket issue	Check and secure all power connections
No image	Wrong input selected	Select correct input (HDMI/USB)
Blurry image	Lens not focused	Use auto/electric focus by remote
No sound	Audio muted or disconnected	Increase volume or reconnect device
Image distorted	Incorrect keystone setting	Reset or adjust keystone
Remote not working	Dead or missing batteries	Replace both AAA batteries
Wi-Fi not connecting	Weak signal	Move closer to router
Bluetooth not pairing	Device not in pairing mode	Re-pair within 5m range
Overheating	Blocked ventilation	Turn off, clear vents and restart
USB not detected	Unsupported format	Reformat to FAT32 or NTFS
General system issue	Software error/completed settings	Perform a factory reset

### 11 Register Warranty

Scan the QR code to register your e-warranty now! Registration is mandatory

DEMO VIDEO

Scan the QR code to watch the demo video and explore the features of your projector

RAISE A TICKET

Scan the QR code to submit a ticket and get prompt assistance from our support team.

NEED ASSISTANCE?

☎ +91 80 7097 7097  
 Our support team is available Monday to Saturday, 10:00 AM - 5:00 PM (IST).

# YUVA BOLT

User Manual

**INSTRUCTION MANUAL**

Note: As the product system is updated from time to time, the specific operation content is based on the actual situation.