展开尺寸：220*170mm,折叠后尺寸：110*170mm
[封面&封底材质：300g铜版纸，过哑膜，彩色印刷
内页材质：128g铜版纸，彩色印刷]

WZATCO

YUVA
VIBE
USER MANUAL

WZATCO

PROJECTOR × **uhaleos**

User Manual

NETFLIX · YouTube · JioHotstar · prime video

Safety Instructions

Read all instructions before you use this device. Do not make any changes or create settings that are not described in this manual. If physical damage, loss of data or damage is caused by failure to follow instructions, the warranty does not apply.

1. To reduce the risk of fire or electric shock, do not expose the device to rain or moisture. Objects filled with liquids, such as vases, should not be placed on this device.
2. Do not place this device on soft surfaces such as tablecloths or carpets, otherwise the device could be a fire hazard.
3. Do not place this device in areas susceptible to excessive dust and dirt or near any appliance generating a strong magnetic field.
4. To prevent overheating, do not block or clog the ventilation holes.
5. Never place this device in a confined space. Always leave enough space around this device for ventilation.
6. Protect this device from overexposure to direct sunlight, heat, large temperature fluctuations and moisture. Avoid extreme temperatures.
7. When this device is running for a long period of time, the surface may become hot. Shut it down immediately and unplug the charger. Resume operation after this device has cooled down.
8. Always handle this device with care. Avoid touching the lens. Do not allow children to handle the device without supervision.
9. Use attachments or accessories specified by the manufacturer only.
10. Avoid extreme vibration as it may damage the internal components.

Package List

Projector × 1

Remote Control × 1
(Batteries are not included)

Power Cable × 1

HDMI Cable × 1

USER'S MANUAL

Projector User Manual × 1

Clean Tool × 1

Overview

On / Off

IR receiver

USB Input
HDMI Input
3.5mm Stereo Jack
IR receiver

Power Socket

Tips:
1. Blurry Image
   Click Setting icon on the homepage - Setting - Lens -
   Autofocus Settings to adjust the image clearity.
   Press the focus button on remote control to get the
   best clarity.
2. Mounting Hole
   Adopting a single mounting hole dual-use design, the
   projector is compatible with the standard camera tripod
   and 1/4 inch screw projector tripod stand.

Remote Control

Power

Google Assistant

Bluetooth Speaker

Input

Setting

D-Pad with center select

Back

Home

VOL + / −

Mute

Netflix

Disney +

Menu

TV Casting

Focus +/−

YouTube

Prime Video

WZATCO

Note: the matching interface of Bluetooth remote control, Press "Voice input" button to bring up the matching guide.

bluetooth remote controller pairing:
Please keep the Remote Controller close to the Projector, press and hold Left button and Right button for three seconds to pair.

Getting Started

Plug the power cable to the projector.
Press power button to turn on the projector.

Use the manual focus by pressing the "Focus" button on the remote control.

Tips:
Make sure the projector is horizontal to the projector screen.

Cleaning Method

1. Get the screwdriver ready, unscrew the screws.

3. Clean the projector by the cotton swab.

4. Reinstall the bottom cover after cleaning.

Network Setting

⚙ Click Setting icon on the homepage – Setting – Wireless and Network – Wired or Wifi – Connect to netword > Choose the network and type the password that you want to connect to.

Bluetooth Setting

⚙ Click Setting icon on the homepage – Setting – Wireless and Network – Bluetooth – Search for Bluetooth device > Click search and pair the device that you want to connect to.

CEC Setting

⚙Click Setting icon on the homepage - Setting - Wireless and Network - HDMI CEC - CEC > Enable CEC, CEC devices such as TV sticks can be controlled remotely with remote control.

Picture Setting

⚙Click Setting icon on the homepage - Setting - Picture > Perform personalized picture settings, change picture mode, set eye protection mode, set noise reduction DLC.

Sound Setting

⚙ Click Setting icon on the homepage – Setting – Sound >
Set the sound quality balance of the machine sound,
adjust the sound mode, set the AVC, surround effect, and
choose the output device and output format of the sound.

🌐 Wireless and n..	Balance 0 ⌄
🖼 Picture	Sound Mode Standard ⌄
🔊 **Sound**	AVC ⬤
🕐 Lens	Surround ⬤
	Audio Output Devices Auto(Speaker) ⌄
☰ Device Preferen..	Select formats Automatic ⌄
⚙ App setting	
🎤 Voice service	
Software Update	

Lens Setting

⚙ Click Setting icon on the homepage – Setting – Lens >
Set the projection direction, autofocus, keystone
correction, digital zoom.

🌐 Wireless and n..	Projection direction Front ⌃
🖼 Picture	Front ✓
🔊 Sound	Rear
	Ceiling front
	Ceiling rear
🕐 **Lens**	Autofocus settings ⌃
	Automatically refocus when moved ⬤
☰ Device Preferen..	Power-on autofocus ⬤
⚙ Android Setting	Keystone correction ⌃
	Auto Keystone Correction ⬤
🎤 Voice service	4-corner correction
	Keystone correction advanced settings
	Reset keystone correction data
Software Update	Digital zoom

Device Preference

⚙Click Setting icon on the homepage – Setting – Device Preference > Change language, set date and time, choose keyboard, set sleep timer, check device information, reset projector, restart projector, whale OS cast, set energy saver, menu timer, location, power desktop.

Whale OS Cast

⚙Click Setting icon on the homepage – Setting – Device Preference – Whale OS Cast > Three mirroring ways are available <TV Casting, DLNA, Miracast>

App Setting

⚙ Click Setting icon on the homepage – Setting – App Setting > Check recently opened applications, view all applications, and app permissions.

🔊 Sound	Recently opened apps ⌄
◎ Lens	View all apps
☰ Device Preferen..	App permissions ⌄
⚙ App setting	
🎤 Voice service	
⬇ Software Update	
🌐 Wireless and n..	

# Voice Service

⚙ Click Setting icon on the homepage – Setting – Voice Service > The language selection and timbre of intelligent speech can be adjusted.

|	
◎ Lens	**Language**
☰ Device Preferen..	Primary Language English (United States) ⌄
⚙ App setting	
🎤 Voice service	**Other Settings**
⬇ Software Update	Timbre AIGenerate1Neural(Mal.. ⌄
🌐 Wireless and n..	Skill ⌄
🖼 Picture	

Software Update

⚙ Click Setting icon on the homepage - Setting - Software Update > Update the software and view the current software information.

File Management

⚙ Insert the U disk, click the File icon on the homepage. The content of U disk could be read, such as video, audio, picture, etc.

Bluetooth Speaker

⚙ Find the Bluetooth speaker icon on the desktop, click to enter the Bluetooth speaker mode.
Search for machine name on your mobile phone, and then pair and connect.
Click <Turning off the screen> to turn off the screen, and press the back button to exit the screen off state.

Speaker mode

SMART2KPJT   waiting for connection......

💡 TURNING OFF THE SCREEN

Bluetooth Speaker

Signal Source

⚙ Click the signal source icon on the homepage, choose HDMI and AV input signal source.

HDMI™

HIGH-DEFINITION MULTIMEDIA INTERFACE

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the
HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

1 YEAR WARRANTY

Scan the QR code
to register your e-warranty now!
Registration is mandatory

DEMO VIDEO

Scan the QR code
to watch the demo video and
explore the features
of your projector

RAISE A TICKET

Scan the QR code
to submit a ticket and
get prompt assistance from
our support team.

NEED ASSISTANCE?

🎧 +91 80-7097-7097
✉ support@wzatco.com
Our support team is available
Monday to Saturday,
10:00 AM – 5:00 PM (IST).